

Gram Opvaskemaskine OM 64435


EAN 5709708237255 · Mål i mm





ANNOTATION:
1.The adjustable height of the machine itself ranges from 0 to 60mm.

2.In addtion, adding height-increasing feet.




Situaction 1:
Without Height-increasing feet, the adjustable height of machine ranges from 0 to 60mm.
A+B(85mm)=85~145mm is available.


Situaction 2:
When adding 40mm height-increasing feet, the adjustable height of machine ranges from 40 to 100mm.
A+C(125mm)=125~185mm is available.

ANNOTATION : In the size overlapping area, both options are available.
For example: To raise the entire machine by 50mm, you can choose the combination of A+B or A+C.


* The following picture shows the installation guidance process for kicking plate




Install the fixing plate according to the hole, and make sure the direction of this part is correct



* The following picture shows the installation guidance process for insert the dishwasher into cabinet





Gram Opvaskemaskine OM 64435

EAN 5709708237255 · Mål i mm

